

USER INSTRUCTIONS

# Zenith Digital Combination Locks

## Private Mode

Private Mode

To Unlock

ENTER CODE  
(4 DIGITS)



TURN HANDLE  
TO OPEN

TURN HANDLE  
TO CLOSE

LOCKS AUTOMATICALLY

Error



Errors will time-out after 4 seconds.  
Unfinished instructions will time-out after 4  
seconds. Always wait for LED lights to finish  
before pressing next key.

