

Private Mode

To Unlock

PRESS



BUTTON



APPLY CARD



TURN HANDLE
TO OPEN

TURN HANDLE
TO CLOSE



LOCKS AUTOMATICALLY

Error



Errors will time-out after 4 seconds.

Unfinished instructions will time-out after 4 seconds.

Always wait for LED lights to finish before pressing next key.